

Maintenance

No.	Maintenance cycle/ Maintenance items	General maintenance requirements for driving under normal conditions	Mileage (km)	
			First 30,000	Every 30,000
			Time (month)	
			First 24 months	Every 24 months
28	Replace reducer lubricating fluid (including the oil drain plug gasket) every 30,000 km		Special maintenance item	
29	Replace brake fluid every 24 months or 60,000 km (whichever comes the first)		Special maintenance item	
30	Replace coolant every 24 months or 60,000 km (whichever comes the first)		Special maintenance item	

Note:

- The maintenance content of this table is applicable to our company manufactured pure electric series vehicle and selection of maintenance items shall depend on vehicle features.
- The maintenance interval of air filter element and AC ventilation system element shall be shortened for vehicles running in the environment full of dust.
- Tire rotation every 5,000 to 10,000 km based on tire wear and then tire pressure correction.

Maintenance record part

Maintenance record

Maintenance record	Maintenance record
Maintenance date: <u>08/24</u> Odometer reading: <u>17403</u> Km	Maintenance date: _____ Odometer reading: _____ Km
Record items: <u>gearoil change</u>	Record items: _____
 <p>Monaghan Bros Main St, Lisnaskea Tel. 02867721354 www.monaghanbros.co.uk</p>	
Name of authorized Service Provider: <u>Stamp of authorized Service Provider:</u>	Name of authorized Service Provider: Stamp of authorized Service Provider:
Next maintenance engagement Date: <u>08/25</u> Mileage: <u>36000</u> Km	Next maintenance engagement Date: _____ Mileage: _____ Km